Event Tone Wireless
Making Wireless Easy

Thank you so much for your trust in EventTone Wireless. We always appreciate your business.

Enclosed, please find your order.

In your case you will find FedEx return-shipping labels. At the conclusion of your rental, please place all the EventTone Wireless rented equipment back in to the case, affix the label, apply the plastic ties, and give to any FedEx Ground currier. If you have trouble finding a currier, please give us a call at 855-396-5450 and we'll make the arrangements to have it picked up for you. It is helpful for us to receive the equipment back as efficiently as possible.

At EventTone Wireless, all of our equipment is fully charged before shipping. However, like other electronic equipment, radios will lose some charge over time, even if unused. We recommend, if you have the time and ability, to set up the chargers and "top off" the radios to assure a complete charge for your needs. Also, all equipment is fully tested to assure they are functioning properly before we ship. However, items can become damaged during shipping. Upon receipt of your order, please review and confirm everything is working properly. If not, please notify us immediately and a replacement will be sent free of charge. If you do not notify us, you may be charged for the damaged items.

If you have any concerns or problems, or if you need amend your order in any way, please give us a call. We're here for you whenever you need us.

Thank you again for your business.

EventTone Wireless

Hytera
Respond & Achieve

Radio Guide for

Left View

LED Indicator

Push to Talk Button

Short Press

Long Press

Speaker

Microphone

Front View

Channel Knob

Power / Volume Knob

Accessory / Programming Port

Scroll Up

Menu / Select

Short Press

Long Press

Short Press

Long Press

Scroll Down

Back

Short Press

Long Press

Short Press

Long Press

Short Press

Long Press

Radio Operation

Charging the Radio

- Please ensure the radio is off when charging
- Charging while the radio is on shortens the lifespan of your battery
- Full charge may take up to 3 hours
- The radio should be placed in the charger with the screen (front of radio) facing the front of the charger.

Turning the Radio On

- Rotate the on / off volume knob to power on & set the volume
- If the radio is tuned to a non-programmed channel it will emit a continuous error tone
- Please reference the zone / channel list to select the appropriate channel

Viewing Text Messages

- When the radio receives a text message it will beep, vibrate & display a mail icon
- Pressing the select button will allow you to view the message
- If multiple messages have been received, pressing the select button will display a list of messages
- You can highlight the messages using the scroll button
- Pressing the select button again will allow you to view the highlighted message

Sending Text Messages

- To send a text, press the select button to display the menu
- Use the scroll button to scroll down to the quick text option & press the select button
- This will display the pre-programmed text messages
- Use the scroll button to scroll until the desired message is highlighted then press the select button
- Once completed, press the select button to confirm & select the send option, then select contact list
- Use the scroll button to scroll to the desired contact & press the select button to send

Transmitting Voice Calls

- To initiate a transmission hold the Push to Talk (PTT) Button
- Once you press the PTT Button, the radio will emit a talk permit chirp
- This talk permit chirp signals that you can begin to speak
- When done speaking release the PTT Button
- For a set period of time the system resources are held to allow immediate responses
- If there is no response within this period the system will be released signaled by a call ended chirp

Transmitting Voice Calls Out of Talkgroup

- To call outside your talkgroup press the contact list button to bring the list on the screen
- Use the scroll button to highlight the desired contact
- Press the PTT Button & you will transmit on the selected contact's talkgroup
- The radio will stay on the selected group until a set time of inactivity or canceled via the home button

Receiving Voice Calls

- Portables automatically receive transmissions on the Talkgroup
- When receiving the screen will display the Talkgroup & the Radio ID / Alias of the transmitting unit

Channel Controls

- There are _____ zones
- Each zone has _____ channels programmed
- To switch zones
- To switch channels Turn the Channel Knob

Please Open & Read